

Kingston Water Department

111 Jansen Ave. Kingston, NY 12401 845-331-0175

SAMPLE COLLECTION INSTRUCTIONS

- 1. Samples are ONLY to be collected in sterile laboratory bottles. Keep the sample bottle closed until the moment it is to be filled.
- 2. Select a tap that is representative of your system. Do not use leaky taps. Remove screens, splashguards or other faucet attachments.
- 3. Open the tap fully and allow the water to run for 2 to 3 minutes.
- 4. Carefully remove the cap from the sample bottle. Do not handle the inside of the cap or the neck of the bottle. AVOID CONTAMINATION.
- 5. Restrict the flow of water to permit filling of the bottle without splashing.
- 6. Fill with cold water to the neck of the bottle.
- 7. Replace the cap tightly on the sample bottle.
- 8. Refrigerate the samples if transport back to the KWD is delayed. Samples dropped off in the morning, will be set-up that afternoon. Samples dropped off in the afternoon will be set-up the following day. No more than 24 hours can elapse between samples collection and set-up in the lab for total coliform analysis. Please plan accordingly.

NO MORE THAN 24 HOURS MAY LAPSE BETWEEN COLLECTION OF THE SAMPLE AND ITS SET-UP FOR TOTAL COLIFORM ANALYSIS

SAMPLE DROP OFF HOURS: 9:00 AM TO 4:00 PM Monday thru Wednesday

9:00 AM to 12:00 PM Thursday

No samples accepted on Fridays or the day before a holiday.

The fee for each Total or Fecal Coliform analysis is \$35.00. Fees are payable when the sample is received by check or cash only. Total or Fecal Coliform analysis can take up to 4 days to complete. There is nothing that the staff can do to speed up the process. Therefore, please allow up to 7 business days to receive the results in the mail.